




P&G EnergyVue®

P&G WinGuard®
VINYL


FD5455 / FD5555

This reference guide is to help identify parts you may need.


FRAME PARTS



Head and Jamb




Threshold w/ Anchor Plate & Threshold Cover




Head & Jamb Installation Screw Cover




Threshold Installation
Screw Cover



Threshold Cover



Drip Cap



Anchor Plate



Add-on Front Flange



Hinge



Frame Hinge Screw



Frame Hinge
Masonry Fastener




Adjustable Rhino
Strike Plate




Center Strike Plate


SLAB PARTS




Stile, Top & Bottom Rail




Single Door Astragal Cap




Double Door Active Astragal Cap



Double Door Inactive Astragal Cap




Comparison of Active versus Inactive



Hinge Trim Cover



Inactive Flushbolt



Flushbolt Guide




Double Door Active Astragal End Seal




Double Door Inactive Astragal End Seal




Panel Hinge Screw



SIDELITE & TRANSOM PARTS



Anchor Plate



Screw Cover

HARDWARE



Series 800 Active Handle Set



Series 800 Inactive Handle Set



Series 100 Active Handle Set



Series 100 Inactive Handle Set




Key-alike Cylinder - Satin Nickel



XX Kit

FRENCH DOOR EXPLODED VIEW



PARTS LIST	
ITEM	NAME
1	800 Series Handle Set (Active)
2	800 Series Handle Set (In-Active)
3	100 Series Handle Set (Left Hand)
4	100 Series Handle Set (Right Hand)
5	Hinge
6	Center Strike Plate and Screws
7	6/8 High Multipoint Rhino Lock
8	8/0 High Multipoint Rhino Lock
9	Flushbolt Rod - Top and Bottom - Up to 6/8
10	Flushbolt Rod - Top - Over 6/8
11	Flushbolt Guide
12	In-Active Slab Dust Plug
13	Double Door Active Astragal Cap
14	Double Door In-Active Astragal Cap